



## STANDARD TRAILER SPECIFICATIONS

### 6' Wide Measurements

#### Interior Measurements:

Subtract 3" from size = interior length

Example: 6x12 = 11'9" interior length

Plus add a 20" V nose

68" interior width

75" interior height

#### Rear Door Entry Measurements:

62" wide rear door opening

60" between the cables

69" high rear door opening

#### Exterior Measurements:

Add 3'6" to box length for tongue

Example: 6x12 = 15'6" exterior length

7'6" total width (includes fenders)

8'2" total exterior height

(8' without roof vent)

Ground clearance 14" to bottom of frame

### 7' Wide Measurements

#### Interior Measurements:

Subtract 3" from size = interior length

Example: 7x16 = 15'9" interior length

### Empty Trailer Weight

6X12SA - 1200 LBS

6X14SA - 1300 LBS

6X10TA - 1200 LBS

6X12TA - 1800 LBS

6X14TA - 2060 LBS

6X16TA - 2260 LBS

6X18TA - 2460 LBS

7X10SA - 1200 LBS

7X12SA - 1300 LBS

7X14SA - 1400 LBS

7X12TA - 1960 LBS

7X14TA - 2120 LBS

7X16TA - 2260 LBS

7X18TA - 2480 LBS

7X20TA - 2640 LBS

8X12TA - 2400 LBS

8X14TA - 2600 LBS

8X16TA - 2800 LBS

8X18TA - 3000 LBS

8X20TA - 3200 LBS

8X22TA - 3400 LBS

8X24TA - 3600 LBS

8.5X16TA - 2800 LBS

8.5X18TA - 3000 LBS

8.5X20TA - 3200 LBS

8.5X22TA - 3400 LBS

8.5X24TA - 3600 LBS

Plus add a 20" V-nose  
80" interior width  
75" interior height

**Rear Door Entry Measurements:**

75" wide door opening  
72" between the cables  
69" high rear door opening

**Exterior Measurements:**

Add 3'6" to box length for tongue  
Example: 7x16 = 19'6" total length  
8'6" total width (includes fenders)  
8'4" total exterior height  
(8'2" without roof vent)  
Ground clearance 14" to bottom of frame

**8.5' Wide Measurements**

**Interior Measurements:**

Subtract 3" from size = interior length  
Example: 8.5x20 = 19'9" interior length

Plus add a 24" V-nose

8' interior width from wall to wall  
83.5" between wheel wells  
Interior wheel wells 6"W x 9"H x 72"L  
6'6" interior height

**Rear Door Entry Measurements:**

90" wide rear door opening  
87.5" between the cables  
74" high rear door opening

**Exterior Measurements:**

Add 3'6" to box length for tongue  
Example: 8.5x20 = 23'6" total length  
8'6" total exterior width  
8'7" total exterior height or 8'5" no roof vent  
Ground clearance 15" to bottom of frame